



D-903

D-903 PLUS

STARTING MANUAL

MAINTENANCE

DOSAGE

SPARE PARTS

Please read and follow this operating manual before putting the machine into operation.



SOLÀ seed drills and fertilizer spreaders are manufactured in a highly specialized environment and our factory has a vast network of satisfied customers.

SOLÀ machines use highly advanced technology and are guaranteed to work without malfunctions in a large variety of conditions. They SOLÀ machines are provided with easy-to-use and efficient devices and perform excellently with only minimum operator maintenance.

This manual will help you use your SOLÀ product with the maximum efficiency.



Certified quality system

10th Edition - October 2014
Ref.: CN-811025/GB
Created by: INTEGRUM

It is forbidden to copy any part of this manual.
Specifications are subject to change or modification without notice.
The pictures included do not necessarily show the standard version.

TABLE OF CONTENTS

| | |
|--|-----------|
| 1. INTRODUCTION | 5 |
| 2. TECHNICAL CHARACTERISTICS..... | 6 |
| 2.1 OVERVIEW | 6 |
| 2.2 STANDARD EQUIPMENT..... | 7 |
| 2.3 OPTIONAL EQUIPMENT..... | 7 |
| 3. SAFETY INSTRUCTIONS | 7 |
| 3.1 SAFETY SYMBOLS | 7 |
| 3.2 USE ACCORDING TO DESIGN..... | 8 |
| 3.3 GENERAL SAFETY INSTRUCTIONS | 8 |
| 4. ESSENTIAL SPREADING CONCEPTS | 9 |
| 4.1 FACTORS TO BE TAKEN INTO ACCOUNT FOR A GOOD SPREADING | 9 |
| 4.2 FERTILISER SPREADING..... | 9 |
| 5. STARTING | 10 |
| 5.1 COUPLING TO THE TRACTOR..... | 10 |
| 5.2 PTO SHAFT | 10 |
| 5.3 COUPLING THE TRAILED FERTILISER SPREADER TO THE TRACTOR | 11 |
| 5.4 HYDRAULIC CONNECTIONS OF THE BOUNDARY SPREADING LIMITER IN FERTILISER SPREADERS D-903 & D-903PLUS..... | 11 |
| 6. COMMON ADJUSTMENTS IN FERTILISER SPREADERS D-903 & D-903 PLUS..... | 12 |
| 6.1 SUMMARISED METHOD FOR ADJUSTING | 12 |
| 6.2 KNOWLEDGE OF THE PHYSICAL CHARACTERISTICS OF THE FERTILISER | 12 |
| 6.3 FLOW ADJUSTMENT..... | 13 |
| 7. ADJUSTING THE WORKING WIDTH FOR FERTILISER SPREADER D-903 (UP TO 24 MM) | 13 |
| 7.1 INTERPRETATION OF THE TABLES WHICH ADJUST THE WORKING WIDTH OF THE FERTILISER SPREADER D-903 | 14 |
| 8. INTERPRETATION OF THE TABLES WHICH ADJUST THE WORKING WIDTH OF THE FERTILISER SPREADER D-903 PLUS .. | 14 |
| 9. CALIBRATION TEST | 16 |
| 10. BOUNDARY AND SIDE SPREADING | 17 |
| 10.1 BOUNDARY SPREADING BY REDUCING THE FERTILISER'S FLOW IN MODEL D-903 | 17 |
| 10.2 HIDRAULIC CONNECTIONS OF THE BOUNDARY SPREADING LIMITER IN FERTILISER SPREADERS D-903 & D-903 PLUS | 17 |
| 11. MAINTENANCE..... | 18 |
| 11.1 LUBRICATION | 18 |
| 11.2 SCREWS | 18 |
| 12. DOSAGE TABLES | 18 |
| 12.1 SYMBOLS USED IN THE TABLES FOR D-903 | 18 |
| 12.2 SYMBOLS USED IN THE TABLES FOR D-903 PLUS | 19 |
| 13. ASSEMBLING THE CONVERSION KIT FROM 24M TO 30-36 M IN MODEL D-903 | 22 |
| 14. ASSEMBLING THE CONVERSION KIT FROM 30-36 M TO 24 M IN MODEL D-903 PLUS..... | 23 |
| 15. SPARE PARTS | 24 |
| 15.1 CHASSIS D-903 : D-903 PLUS | 24 |
| 15.2 FRONTAL FRAME D-903/3000 : D-903 PLUS/3000 | 26 |
| 15.3 FRONTAL FRAME COMPL. D-903/3000 : D-903 PLUS/3000 | 28 |
| 15.4 FERTILIZER FENDERS D-903/3000 | 30 |
| 15.5 FERTILIZER HOPPER D-903 Y D-903 PLUS | 32 |
| 15.6 REGULATION, DISTRIBUTION AND TRANSMITION D-903 PLUS | 34 |
| 15.7 REGULATION, DISTR. AND TRANS. D-903 Y D-903/3000 | 36 |
| 15.8 CONVERSION KIT 36 TO 24 METERS | 38 |
| 15.9 CONVERSION KIT 24 TO 36 METERS | 40 |
| 15.10 HYDRAULIC CONTROL FERTILIZER D-903 Y D-903 PLUS | 42 |
| 15.11 SHORT LIMITER (MECH.L/HYDRAULIC) D-903 Y D-903 PLUS | 44 |
| 15.12 SHORT LIMITER D-903/3000; D-903 PLUS/3000 | 46 |
| 15.13 TRANSMITION | 47 |
| 15.14 FERTILIZER D-903/3000 | 48 |

TABLE OF CONTENTS

1. INTRODUCTION

It is essential to read and follow the instructions and recommendations in this manual before operating the fertiliser spreader **D-903** or **D-903 PLUS**. Careful reading enables maximum operator efficiency, prevents accidents and damage, and increases the fertiliser spreader capacity and life expectancy.

Please ensure that this manual has been read by any person involved in performing **operational tasks**, (including preparation, dealing with mechanical problems and supervising the machine), **maintenance** (inspection and technical assistance) and **transport**.

For your safety, please follow these technical safety instructions as **SOLÁ** will not be responsible for damages caused by not observing the information provided.

In the first chapters you will find the Technical Characteristics and Safety Instructions, as well as some essential sowing concepts. Basic concepts that are required to operate the machine are explained in the Starting and Maintenance sections.

The last part of this manual consists of Dosage Tables, detailed by seed type.



SOLÁ RETAINS THE RIGHT TO MODIFY ILLUSTRATIONS, TECHNICAL DATA AND WEIGHTS INDICATED IN THIS OPERATING MANUAL, IF THESE CHANGES HELP TO IMPROVE THE QUALITY OF THE FERTILISER SPREADERS.

In this operating manual you will find three different symbols relating to safety:



TO WORK MORE EASILY WITH THE FERTILISER SPREADERS.



TO PREVENT DAMAGE TO THE FERTILISER SPREADER AND OPTIONAL EQUIPMENT.



TO PREVENT PHYSICAL INJURY.


2. TECHNICAL CHARACTERISTICS

| MODEL | CAPACITY | WIDTH | LENGTH | HEIGHT | WEIGHT (KG) |
|------------|----------|----------|----------|----------|-------------|
| D-903/1000 | 991 l | 2.400 mm | 1.342 mm | 970 mm | 302 Kg |
| D-903/1200 | 1.191 l | 2.400 mm | 1.342 mm | 1.070 mm | 316 Kg |
| D-903/1500 | 1.491 l | 2.400 mm | 1.342 mm | 1.140 mm | 334 Kg |
| D-903/2000 | 1.928 l | 2.400 mm | 1.342 mm | 1.260 mm | 347 Kg |
| D-903/3000 | 2.600 l | 2.400 mm | 3.100 mm | 1.870 mm | 760 Kg |

| | |
|---|--|
| PTO shaft turning speed | 540 r/min |
| Discs turning speed | 675 r/min |
| Spacing between the discs's centers | 1.140 mm |
| Working width D-903 | 15 a 24 m |
| Working width D-903 PLUS | 30 y 36 m |
| Adjustment of the working width | By means of spreading vanes and funnel |
| Spreading vanes per disc in D-903 | 3 |
| Spreading vanes per disc in D-903 PLUS | |

2.1 OVERVIEW

Fig. 1



2.2 STANDARD EQUIPMENT

- Hopper's bases, agitators, discs, funnels and spreading vanes, all of them made of inox steel.
- Non-agressive slow-turning agitator.
- Ability to close the right outlet at the field boundaries and sides.
- Mechanically actuated boundary spreading limiter.
- Easy performance calibration test with both supplied calibration channel and calibration cup.
- Granulometer.
- Position lamps, indicators and brake lights.
- Protective tube at rear and at side to prevent contact with the turning PTO shaft.
- PTO shaft with friction clutch and protection.

- Ability of spreading at medium height (only D-903).
- Three-point linkage of attachment category II.

2.3 OPTIONAL EQUIPMENT

- Hydraulically actuated boundary spreading limiter.
- Conversion kit 24-36 m for D-903.
- Conversion kit 36-24 m for D-903 PLUS.
- Mechanical remote for opening and closing the fertiliser outlets.
- Hopper cover.

3. SAFETY INSTRUCTIONS

3.1 SAFETY SYMBOLS

On the machine you will find the following warning pictograms:



READ THE INSTRUCTIONS CAREFULLY AND OBSERVE THE SAFETY ADVICE GIVEN IN THE OPERATING MANUAL.



DURING THE COUPLING MANOEUVRE, STAY AWAY FROM THE REAR PART OF THE TRACTOR.
RISK OF SERIOUS PHYSICAL INJURY.



DANGER OF INFECTION FROM ESCAPING HYDRAULIC FLUID AT HIGH PRESSURE! THIS CAN INFECT SERIOUS INJURIES WITH POTENTIALLY FATAL CONSEQUENCES IF IT PASSES THROUGH THE SKIN AND INTO THE BODY.
KEEP THE HOSE LINES IN GOOD CONDITION.
RISK OF SERIOUS PHYSICAL INJURY.



RISK OF SERIOUS PHYSICAL INJURY.



WHILE MAINTAINING OR REPAIRING THE FERTILISER SPREADER, STOP THE TRACTOR'S ENGINE AND PREVENT IT FROM STARTING. THE IGNITION KEY MUST BE REMOVED.



RISK OF BEING CRUSHED WHEN WORKING UNDER THE MACHINE, PLEASE SECURE THE MACHINE TO PREVENT THIS RISK.

RISK OF SERIOUS PHYSICAL INJURY.



THE DIRECTION AND SPEED THAT THE PTO SHAFT TURNS (ONLY IN MACHINES EQUIPPED WITH MECHANICAL FAN).



WARNING!
Max. weight: 1,490 kg

DO NOT EXCEED MAXIMUM LOAD.



COUPLING POINT FOR TRANSPORTATION BY CRANE.

3.2 USE ACCORDING TO DESIGN

- Fertiliser spreaders **D-903 & D-903 PLUS** have been designed for normal use in agricultural work, especially for spreading with mineral products.
- If the machine is used in circumstances other than the above, SOLÁ will not be held responsible for any damage caused.
- The user must observe all regulations concerning safety, traffic and hygiene.
- If the machine is modified by the user, the manufacturer's warranty is cancelled.
- **SOLÁ** will not be held responsible for any damage caused.

3.3 GENERAL SAFETY INSTRUCTIONS



BEFORE STARTING THE MACHINE, PLEASE CHECK THE MACHINE IS IN GOOD CONDITION FOR WORK AND IS SAFE FOR ROAD USE.



CHECK THAT VISIBILITY IS CLEAR AROUND THE MACHINE AND THERE IS NO PERSON IN THE WORKING AREA.



IN THOROUGHFARE, PLEASE OBSERVE TRAFFIC SIGNS AND REGULATIONS.



IT IS FORBIDDEN TO RIDE ON THE MACHINE OR CLIMB INTO THE MACHINE WHEN IT IS RUNNING.



BEFORE USING THE MACHINE, THE USER MUST BE FAMILIAR WITH ALL OPERATING ELEMENTS.



PLEASE BE EXTREMELY CAREFUL WHEN COUPLING AND UNCOUPLING THE MACHINE TO THE TRACTOR.



PLEASE CHECK THAT THE PTO SHAFT IS IN GOOD CONDITION AND WELL PROTECTED. PREVENT THE PROTECTIVE TUBE FROM TURNING BY HOLDING BOTH THE TUBE AND CHAIN PROVIDED FOR THIS PURPOSE.



MOUNT THE PTO SHAFT'S TRANSMISSION ONLY WHEN THE TRACTOR'S ENGINE IS OFF.



BEFORE CONNECTING THE PTO SHAFT, BE SURE THAT THE DANGER ZONE SURROUNDING THE MACHINE IS CLEAR.



NEVER LEAVE THE TRACTOR'S DRIVER'S SEAT WHILE THE MACHINE IS IN OPERATION.



DO NOT DEPOSIT EXTERNAL ELEMENTS INSIDE THE HOPPER.



WHEN MANTAINING THE HYDRAULIC SYSTEM OF THE FERTILISER SPREADER, MAKE SURE THAT IT IS DEPRESSURISED AND THE TRACTOR'S ENGINE IS OFF.



PLEASE REGULARLY CHECK THE CONDITION OF THE TUBES AND HOSEPIPES IN THE HYDRAULIC SYSTEM. THESE PARTS AGE NATURALLY AND THEIR LIFE SHOULD NOT SURPASS 6 YEARS. PLEASE REPLACE WHEN NECESSARY.



WHEN RAISING THE FERTILISER SPREADER, THE FRONT AXLE IS UNLOADED. ENSURE THAT THE MACHINE HAS ENOUGH LOAD TO PREVENT IT OVERTURNING. AT THIS TIME YOU MUST ENSURE THAT THE CONDITION OF BOTH THE STEERING AND THE BRAKES IS OPTIMAL.



DURING TRANSIT WITH THE RAISED FERTILISER SPREADER, BLOCK THE LOWERING SWITCH. BEFORE LEAVING THE TRACTOR, LOWER THE FERTILISER SPREADER ONTO THE GROUND AND REMOVE THE TRACTOR'S STARTING KEY.



ALWAYS USE ENOUGH SUPPORTING ELEMENTS WHEN MAINTAINING THE MACHINE IN A RAISED POSITION TO PREVENT THE MACHINE FROM LOWERING OR FALLING.



FILL THE FERTILISER SPREADER WHEN IT IS IN ON THE GROUND, ENSURE THE TRACTOR ENGINE IS OFF AND THE FERTILISER OUTLET OPENINGS ARE CLOSED.



ALWAYS CONNECT GENTLY THE PTO SHAFT'S CLUTCH IN ORDER TO PROTECT THE FERTILISER SPREADER. OTHERWISE THE MACHINE COULD BE SERIOUSLY DAMAGED.



BE CAREFUL WHEN FILLING THE FERTILISER SPREADER AND TAKING INTO A FIELD WHICH IS FAR AWAY. IT IS POSSIBLE THAT THE FERTILISER COMPACTS AT THE BOTTOM OF THE HOPPER AND THE OUTLET OPENINGS ARE OBSTRUCTED. IN THIS CASE IT WILL BE NECESSARY TO COMPLETELY OPEN THE OUTLETS, LET THE PTO SHAFT'S CLUTCH SLOWLY IN AND SPREAD SOME FERTILISER. AFTER THIS OPERATION, PLACE THE ADJUSTING LEVERS IN THE POSITION CORRESPONDING TO THE CHOSEN FLOW AND SPREAD NORMALLY.



NEVER DELIBERATELY CAUSE THE EXIT OF THE FERTILISER FROM THE UPPER PART OF THE HOPPER. THERE IS A SERIOUS RISK OF OBSTRUCTING THE AGITATOR.



AFTER EACH WORKING DAY, THE SPREADING VANES AND THEIR TIGHTING SCREWS SHOULD BE CHECKED. THEY SHOULD BE REPLACED WHEN THEY ARE VISIBLELY WORN OUT, SINCE THE WEAR IS CAUSED BY THE CONTACT WITH THE FERTILISER AND IT IS BECOMES WORSE WHEN THE FERTILISER IS MORE ABRASIVE.



CONSEQUENCES OF WORN OUT SPREADING VANES ARE A BAD IRREGULAR SPREADING AND, ESPECIALLY, THE RISK CAUSED BY FRAGMENTS DETACHED FROM THE SPREADING VANES.

4. ESSENTIAL SPREADING CONCEPTS


4.1 FACTORS TO BE TAKEN INTO ACCOUNT FOR A GOOD SPREADING

- 1- Fertiliser's granulometry:** Reject fertilisers with grains of irregular size or with grains that break easily. This makes uniform spreading difficult.
- 2- PTO shaft speed:** PTO shaft's speed determines the turning speed of the spreading discs and, consequently, the working width. Speed should be 540 rpm.
- 3- Forward speed:** Variations in forward speed modify the amount of fertiliser spread onto the ground.
- 4- Hopper's position:** The hopper should stay horizontal since lateral or longitudinal lean modify the fertiliser's distribution onto the ground.
- 5- Working height:** The working height should stay constant at 75 cm measured from the disc to the ground. This height should be checked at the field. It should not be checked when coupling the machine in the warehouse.
- 6- Do not fertilise if the weather is windy:** Wind modifies the spreading direction of the fertiliser grains as well as distribution. The wider the working width, the lower the dose and the more irregular the grain size, result in highly uneven spreading in windy conditions.
- 7- Wear and tear of the spreading discs and spreading vanes:** Spreading discs and spreading vanes are essential in the spreading of the fertiliser, and their wear can have great influence when spreading the fertiliser onto the ground. Keep them in optimal condition.
- 8- Check fertiliser's flow:** Perform a previous calibration test in the warehouse in order to know exactly the amount of fertiliser going to be spread. Dosage is going to be very different when using different kinds of fertiliser, as it depends on factors such as density, moisture content, etc...
- 9- Distance between tramlines:** Keeping the distance between tramlines is essential to get optimal spreading. To know this distance, follow the adjusting instructions. To increase the precision, a test at the field could be performed by checking the amount of spread fertiliser using boxes placed on the ground.


4.2 FERTILISER SPREADING

It is well known that the amount of fertiliser spread onto the field directly affects in the output of the harvest.

Nevertheless, what is even more important than the amount of fertiliser is the uniformity in which it is distributed along the terrain. Fertiliser spreaders **D-903 and D-903 PLUS** distribute the fertiliser as shown in the following diagram:



To get a uniform distribution, the fertiliser should be spread overlapping the tramlines so the final result is a flat diagram like the one below:



Uniformity in fertiliser distribution is measured by means of the coefficient of variation (CV). The CV is calculated using a statistical formula based on the data obtained from the overlapping technique.

Fertiliser's manufacturers agree on the fact that CV is very good if it stays below 10%, it is medium if it stays between 10% and 15%, and it is bad if it exceeds 15%. The last case should be avoided.

5. STARTING

5.1 COUPLING TO THE TRACTOR

The fertiliser spreaders **D-903** and **D-903 PLUS** are provided with bolts of category II for their coupling to the tractor's three-point linkage.

To make the coupling easier, the fertiliser spreader is equipped with two supports which, when lowered to a vertical position (Fig. 2), increase the height of the coupling point.





Fig. 2



In working position, the fertiliser spreader should stay horizontally and its disc should be at 75 cm from the ground (Fig. 3).




Fig. 3

5.2 PTO SHAFT

PTO shaft's turning speed should be 540 rpm and it is important to keep this constant while working.




Fig. 4

Once the fertiliser spreader is coupled with the tractor, **THE PTO SHAFT SHOULD BE ADAPTED:**

- 1-** Dismount and insert one end into the tractor's universal joint shaft and the other end into the fertiliser spreader. Look for the minimal movement length "L" (Fig. 5) by raising and lowering the hydraulic lift.
- 2-** Cut the spare plastic and metal into parts of the same length and remount the PTO shaft.
- 3-** Operate the hydraulic lift and check that the PTO shaft's movement is correct.
- 4-** Secure the PTO shaft using the chain.




Fig. 5




Fig. 6




Fig. 7



WHEN OPERATING THE PTO SHAFT CHECK THAT THE ENGINE IS OFF. ALWAYS WORK WITH THE PTO SHAFT PROTECTED AND IN GOOD CONDITION. PREVENT THE PTO SHAFT'S TUBE FROM TURNING BY SECURING IT WITH THE CHAIN PROVIDED.



WHEN LOWERING THE FERTILISER SPREADER TO THE GROUND, UNPLUG THE TRACTOR'S UNIVERSAL JOINT SHAFT SO THAT THE PTO SHAFT DOES NOT HAVE AN EXCESSIVE INCLINATION (MAX. 35°).



WHEN HOLDING THE TRACTOR UNIVERSAL JOINT SHAFT'S CLUTCH IN, PERFORM IT GENTLY. STARTING SUDDENLY COULD SERIOUSLY DAMAGE THE FERTILISER SPREADERS.




Fig. 9

Mount the PTO shaft with the clutch on the fertiliser spreader side. Mounting on the trailede fertiliser spreader.

5.3 COUPLING THE TRAILED FERTILISER SPREADER TO THE TRACTOR

Fertiliser spreaders D-903 and D-903 PLUS Trailed are equipped with a type of coupling (axle-swivelling ring) which can be easily adjusted to different heights.




Fig. 8

Once coupled to the tractor, the fertiliser spreader should stay horizontal. To make it easier, the height of the coupling ring can be adjusted in two different positions.

To switch between heights, simply invert the ring's position. In some cases it is possible that none of the two positions is the correct one to level the fertiliser spreader horizontally. If this is the case, the platina which holds the ring in the right position should be soldered and correctly secured.

Check that the ends of the PTO shaft's telescopic axle (Fig. 9) do not touch when the fertiliser spreader is raised to its working position. Cut these ends, if necessary, leaving a section long enough to ensure a connection of at least 15 cm with the shaft fully extended.



BEFORE CONNECT THE PTO SHAFT CHECK THE MINIMUM MEASURE

5.4 HYDRAULIC CONNECTIONS OF THE BOUNDARY SPREADING LIMITER IN FERTILISER SPREADERS D-903 & D-903PLUS

STARTING:

The plugs in the pilot-operated non-return valve should be connected to the same double-acting connection. From now on, we will name it Connection No. 1. The third plug should be connected to a different connection which will be named Connection No. 2 from now on.

Connection No. 1 determines the working mode, unfolding or folding the boundary spreading limiter.

Connection No. 2 is in charge of opening the fertiliser outlets. When the limiter is unfolded, only the left outlet (in the driving direction) can be opened or closed. On the other hand, when the limiter is folded, both outlets can be opened or closed.





Fig. 10

THEREFORE:

For normal spreading at the center of the field, we should work only with Connection No. 2, making previously sure that the limiter is folded.

For boundary spreading at field edges, first of all the limiter should be unfolded using Connection No. 1 and next, keeping always the field edge at the right side at about 3 metres from fertiliser spreader's centre, the left outlet in the drive direction can be opened and closed using Connection No. 2.



CONNECTIONS IN TRACTORS SHOW OFTEN LEAKS DUE TO INTERNAL WEAR. FOR THIS REASON, DURING TRANSIT OR IN WORK BREAKS IT IS BETTER KEEPING THE LIMITER FOLDED AND THE THIRD PLUG'S TAP CLOSED TO PREVENT THE FERTILISER OUTLETS FROM OPENING.





BE SURE THERE IS NOBODY CLOSE TO THE MACHINE WHEN OPERATING THE HYDRAULIC CONTROLS OR WHEN THE MACHINE IS WORKING.

6. COMMON ADJUSTMENTS IN FERTILISER SPREADERS D-903 & D-903 PLUS


6.1 SUMMARISED METHOD FOR ADJUSTING

The essential workflow steps to adjust the fertiliser spreader are as follows:

1. Knowing the kind of fertiliser, its granulometry, its density, its state (fragments or whole), etc..., to be able to compare it to a similar one found in the tables of chapter 12 of this manual.
2. Knowing the spreading dose in Kg/Ha to be spread, established depending on the kind of both crop, earth and fertiliser.
3. Choosing a working width.
4. Checking the corresponding dosage table and search the desired flow in the squares of Kg/Ha column which depend on the forward speed. Adjust the spreading vanes and the dosing slider as indicated in the table.



5. Perform a calibration test to check that the dosage is correct.



6. Spread a well known and small field to be able to check the instructions explained in the previous points.

6.2 KNOWLEDGE OF THE PHYSICAL CHARACTERISTICS OF THE FERTILISER

Using the same fertiliser spreader adjustments for different fertilisers is not a good way of working, since the spreading of the fertiliser will differ greatly if the fertiliser's physical characteristics are different. Therefore, for each type of fertiliser, a different adjustment needs to be set in the machine.

Physical characteristics which define a particular type of fertiliser are, basically, density and granulometry.

DENSITY:

It is the weight per unit volume. It is measured in Kg/dm³. It can differ depending on the moisture content of the fertiliser. Density of the fertiliser to be used should be compared to the densities found in the dosage tables in chapter 12 of this manual.

GRANULOMETRY:

It shows the ratio between the different grain sizes found in the fertiliser. The granulometry of each fertiliser can be found in the dosage tables. In them, the grain diameter is presented in four groups:

- Ø 4,75 % of grains which diameter exceed 4,75 mm
- Ø 3,3 % of grains with diameters from 3,3 mm up to 4,75 mm
- Ø 2 % of grains with diameters from 2 mm up to 3 mm
- Ø <2 % of grains which diameter is smaller than 2 mm

By convention, the group to which more than 50% of the fertiliser grains belong, determines the type of fertiliser. A fertiliser is considered acceptable when 90% of its granulometric sizes can be found in a maximum of three contiguous groups. To check the fertiliser granulometry, there is a special box with sieves. Thus the fertiliser to be spread can be compared to the ones in the dosage tables in a very easy way.

KNOWLEDGE OF THE PHYSICAL CHARACTERISTICS OF THE FERTILISER:

Fertiliser showing excessive moisture content and dust do not flow correctly and they form vertical walls inside the hopper instead of sliding. Additionally, grains with high moisture content are fragile,


break more easily and their fragments will not reach the same distance than dry and whole grains and therefore the distribution will be worse. For this reason, using this kind of fertiliser needs to be avoided.

6.3 FLOW ADJUSTMENT

In order to adjust the flow, the fertiliser characteristics needs to be determined as indicated in point 6.2 of this manual. Once this is done, the dosage tables need to be consulted to find the most similar fertiliser to the one which is going to be used.

For a chosen dose and working width, search in the tables the square corresponding to this dose (Kg/Ha) in the column that matches the right working width and forward speed.

Once the square corresponding to the chosen dose is located, follow the same row towards the left until the end of the table, where the position of the adjusting lever is indicated. The stop for the lever needs to be placed in that number in the graduated sector.



7. ADJUSTING THE WORKING WIDTH FOR FERTILISER SPREADER D-903 (UP TO 24 M)

The working width in the fertiliser spreader D-903 can be adjusted by means of the position of the spreading vanes. The optimal working width depends on the kind of fertiliser to be used as well as the dose to be spread.

The next table shows the approximate values for the working widths that provide a coefficient of variation (CV) lower than 10 – good – or 15 – medium for three kinds of fertiliser and different doses to be spread. It is recommended to spread at the working widths of the column whose CV is lower (than 10% in order to get optimal results).

| FERTILISER | FLOW (KG/MIN) | DOSE TO BE SPREAD A 8 KG/HA (KG/HA) | WORKING WIDTHS C.V. LOWER THAN 10% (MTS) | WORKING WIDTHS C.V. LOWER THAN 15% (MTS) |
|-------------|---------------|-------------------------------------|--|--|
| NAC | 50 | from 150 to 300 | 24-21-18-15 | |
| | 100 | from 300 to 600 | 24-21-18-15 | |
| | 265 | from 800 to 1.600 | 24-21-18-15 | |
| NPK | 50 | from 150 to 300 | 24-21-18-15 | |
| | 100 | from 300 to 600 | 24-21-18-15 | |
| | 265 | from 800 to 1.600 | 18-15 | 24-21 |
| UREA | 37 | from 150 to 300 | 18-9-15 | 12 |
| | 75 | from 300 to 600 | 18-12-9 | 15 |
| | 199 | from 800 to 1.600 | 18-12-9 | 15 |

Once the optimal working width is determined, the spreading vanes need to be placed at the position indicated in the dosage tables. Note that, for the same working width but using different doses, the spreading vanes are in different positions.

Position of each spreading vane is indicated by means of a letter (A-B-C) and a number (1-2-3).

Letters A, B and C indicate the position of the fixing screw in the

hole of each spreading vane's.





Fig. 16 Left spreading vane view (it should be assembled in the left side disc in the drive direction).

Numbers 1,2 and 3 indicate the position of the spreading vane on the discs's holes.



7.1 INTERPRETATION OF THE TABLES WHICH ADJUST THE WORKING WIDTH OF THE FERTILISER SPREADER D-903

In order to explain how to use the tables which adjust the dosage and the working width, an example is going to be shown.

Let's suppose that we want to spread about 330 Kg/Ha of NAC 27% working at 8 Km/h of forward speed and working at 15 metres between tramlines.

First of all, we need to consult the table corresponding to NAC 27% or, if we are using a different fertiliser with no specific table, we need to chose the table of the fertiliser most similar in granulometry and density.

Once the correct table has been determined, we need to consult the column corresponding to 15 metres and, inside this one, we need to find the 8 km/h column. We will follow the column downwards until we find the closest value to 330 Hg/Ha. In this case it turns out to be 334 Kg/Ha.

At the left of this dosing value, in the column corresponding to the graduated sector's lever position, we are going to find the position for the lever.

At the right of the dosing value we will find the position for the funnels and the position of the spreading vanes on the discs.

| INPUT | | 15 | | | | Kg/Ha | |
|-------|----|-----|------|-----|------|-------|----|
| | m | | | | | Km/h | |
| | | 6 | 8 | 10 | 12 | | |
| 4 | 10 | 131 | 98.5 | 79 | 65.7 | | 1 |
| 5 | 15 | 205 | 154 | 123 | 103 | | C2 |
| 6 | 21 | 281 | 210 | 168 | 140 | | C2 |
| 7 | 27 | 360 | 270 | 216 | 180 | | B2 |
| 8 | 33 | 440 | 334 | 267 | 223 | | |
| 9 | 40 | 539 | 405 | 324 | 270 | | |

The doses that can be found in the tables are approximative, they can differ in fertilisers of the same type due to moisture, granulometry, density, etc.

To know exactly the needed dose (in Kg/Ha) of the fertiliser we are going to use, for a determined position of the lever in the graduated sector, it is recommended to perform calibration tests with the calibration channel which is supplied with the machine, following the instructions detailed in this manual.




Fig. 18

8. INTERPRETATION OF THE TABLES WHICH ADJUST THE WORKING WIDTH OF THE FERTILISER SPREADER D-903 PLUS

The fertiliser spreader D-903 PLUS allows working widths of 30 and 36 metres with fertilisers of the right physical characteristics.

For a chosen fertiliser dose (Kg/Ha), the machine can be adjusted in any of the two working widths by means of the dosage tables. They show the positions for the spreading vanes and their extensions, the funnels and the flow regulator.




Fig. 19

Due to the trapezoidal shape of the spread, it is very important to

keep the distance between tramlines to correctly spread the fertiliser along the field.

We are going to use an example in order to explain how to use the tables to adjust the dose and the machine's working width.

Let's suppose we want to spread about 170 Kg/Ha of NPK 10-10-15, working at 8 Km/h and 30 metres between tramlines.


First of all, we need to consult the table corresponding to NPK 10-10-15 or, if we are using a different fertiliser with no specific table, we need to chose the table of the fertiliser most similar in granulometry and density.

Once the correct table has been determined, we need to consult the column corresponding to 30 metres and, inside this one, we need to find the 8 km/h column. We will follow the column downwards until we find the closest value to 170 Hg/Ha. In this case it turns out to be 171 Kg/Ha.

On the left hand side of this dosing value, in the column corresponding to the graduated sector's lever position, we are going to find the position for the lever.

On the right of the dosing value we will find the position for the funnels as well as the position and extensions of the short spreading vane and the long spreading vane (in this order). This positions are the same for both discs.

INTERPRETATION OF THE TABLES WHICH ADJUST THE WORKING WIDTH OF THE FERTILISER SPREADER D-903 PLUS



The doses that can be found in the tables are approximative, they can differ in fertilisers of the same type due to moisture, granulometry, density, etc.

To know exactly the dose needed (in Kg/Ha) of the fertiliser we are going to use, for a determined position of the lever in the graduated sector, it is recommended to perform calibration tests with the calibration channel which is supplied with the machine, following the instructions detailed in this manual.




Fig. 20




Fig. 23

HOLES IN THE LEFT SHORT SPREADING VANE
(THE RIGHT ONE HAS THE SAME NAMES)





Fig. 24

HOLES IN THE LEFT LONG SPREADING VANE
(THE RIGHT ONE HAS THE SAME NAMES)


NAMES OF THE DIFFERENT HOLES IN SPREADING DISCS AND SPREADING VANES IN THE FERTILISER SPREADER D-903 PLUS



9. CALIBRATION TEST

In order to know the fertiliser flow to be spread by the fertiliser spreader, the amount of fertiliser that comes out from one of the outlet opening in one minute needs to be measured. Using the result of this measurement, the amount in Kg/Ha to be spread will depend only on the forward speed and the space between tramlines.



Fertiliser spreaders **D-903 and D-903 PLUS** allow calibration tests to be performed in the following way:






1. Remove the left spreading disc (in the drive direction) by freeing the ring pin (1, Fig. 26) which is at the lower part. Remove the left spreading disc (in the drive direction) by freeing the ring pin (1, Fig. 25) which is at the lower part.

2. Place the funnel's position indicator (2, Fig. 27) in No. 7 and place the calibration channel as indicated in the upper figure.

3. Fill the left side of the hopper with fertiliser.



4. Place the calibration cup under the calibration channel.
5. Place the stop of graduated sector's lever at the desired position.
6. Start the machine at 540 rpm and open the outlet for a minute (take as a guidance the doses shown in the tables, because one minute in position No. 12 will allow about 50 Kg of a fertiliser to come out, with an specific weight around 1 Kg/L).



7. WeighT the fertiliser that is in the calibration cup (so to directly obtain the value of the flow in Kg/min). To know the dose in Kg/Ha, apply the following formula:

$$\text{DOSE (kg/ha)} = \frac{1200 \times \text{FLOW (kg/min)}}{\text{SPEED (km/h)} \times \text{WORKING WIDTH (m)}}$$

If the flow rate is very high, reduce the time during which the outlet is opened to $\frac{1}{2}$ min or to $\frac{1}{4}$ min, taking then into account that the dose will need to be multiplied by 2 or 4 respectively.

10. BOUNDARY AND SIDE SPREADING

10.1 BOUNDARY SPREADING BY REDUCING THE FERTILISER'S FLOW IN MODEL D-903



TO PREVENT ACCIDENTS, WHEN OPERATING THE FUNNEL IN THE TURNING DISCS ZONE, IT IS ESSENTIAL THAT THE ENGINE IN THE TRACTOR IS OFF.

When starting to work at half of the working width, it is necessary to work with both spreading discs together but the funnel's lever (P) needs to be in position 7. Thus, the side in which the funnel's position has been changed, will have its fertilizer's spreading reduced to half the working width.





Fig. 32



SPREADING OF THE FERTILIZER AT HALF THE WORKING WIDTH

10.2 HIDRAULIC CONNECTIONS OF THE BOUNDARY SPREADING LIMITER IN FERTILISER SPREADERS D-903 & D-903 PLUS




Fig. 33

STARTING:

The plugs in the pilot-operated non-return valve should be connected to the same double-acting connection. From now on, we will name it Connection No. 1. The third plug should be connected to a different connection, let's name it Connection No. 2.

Connection No. 1 determines the working mode, unfolding or folding the boundary spreading limiter.

Connection No. 2 is in charge of opening the fertiliser outlets. When the limiter is unfolded, only the left outlet (in the driving direction) can be opened or closed. On the other hand, when the limiter is folded, both outlets can be opened or closed.

THEREFORE:

For a normal spreading at the center of the field, we should work only with Connection No. 2, making previously sure that the limiter is folded.

For spreading at field edges, first of all the limiter should be unfolded using Connection No. 1 and next, keeping always the field edge at the right side at about 3 metres from the fertiliser spreader's centre, the left outlet in the drive direction can be opened and closed using Connection No. 2.





Fig. 34



11. MAINTENANCE

11.1 LUBRICATION


PTO's shaft and the boundary spreading limiter need to be greased daily.

After using the fertiliser spreader, it is recommended to wash it using hosepipes.

In order to make the washing easier, raise the hopper unlocking the locking hooks which fix it on each side of the chassis.

The gear box uses grease type NLGI 00. Periodically check the grease level by removing the filling cap and refill if necessary.

Do not fold down the hopper with the 1000 L hopper extension being assembled, since the fertiliser spreader would overturn.



The trailers for fertiliser spreaders D-903 and D-903 PLUS are equipped with two balloon wheels type 12,5/80-15/3, providing good suspension and stabilization.
Recommended tyre pressure is 7 Kg/cm².

11.2 SCREWS

All the screws used in the fertiliser spreader are size 8.8.



AFTER WORKING FOR SOME HOURS, ALL SCREWS SHOULD BE CHECKED AND TIGHTENED.

12. DOSAGE TABLES



THE DOSAGE TABLES INDICATE THE SPREAD DOSES IN KG/HA FOR EACH KIND OF FERTILISER, DEPENDING ON THE WORKING WIDTH AND THE FORWARD SPEED.



THE INDICATED QUANTITIES ARE APPROXIMATIVE, SINCE THE PREDICTED FLOW CAN DIFFER DUE TO THE VARIETY OF GRANULOMETRY, DENSITY, MOISTURE, ETC.



FOR FERTILISERS NON SPECIFIED IN THE TABLES, USE THE ONE WHICH IS MOST SIMILAR IN GRANULOMETRY AND DENSITY.

12.1 SYMBOLS USED IN THE TABLES FOR D-903



WORKING WIDTH OR SPACING BETWEEN TRAMLINES.



POSITION OF THE ADJUSTING LEVER.

kg/min

FLOW OF ONE OUTLET, IN KG/MIN.

km/h

FORWARD SPEED IN KM/H.




POSITION OF THE SPREADING VANES ON THE DISC.



POSITION OF THE FUNNEL.

12.2 SYMBOLS USED IN THE TABLES FOR D-903 PLUS



WORKING WIDTH OR SPACING BETWEEN TRAMLINES.



POSITION OF THE FUNNEL.



POSITION OF THE ADJUSTING LEVER.

kg/min

FLOW OF ONE OUTLET, IN KG/MIN.



B1 SHORT SPREADING VANE'S HOLE ON DISC'S HOLE.
E4 EXTENSION OF THE SHORT SPREADING VANE.

km/h

FORWARD SPEED IN KM/H.



A4 LONG SPREADING VANE'S HOLE ON DISC'S HOLE.
E9 EXTENSION OF THE SPREADING VANE.

| | | D-903 | | | | | | | | | | | | TABLE 1 | | | | | | | |
|----|---------------|-------|------|------|------|-------|------|------|------|-------|----|------|------|---------|------|----|------|------|------|------|----|
| | | 15 | | | | 18 | | | | 21 | | | | 24 | | | | | | | |
| | Kg/min | Kg/Ha | | | | Kg/Ha | | | | Kg/Ha | | | | Kg/Ha | | | | | | | |
| | | 6 | 8 | 10 | 12 | 6 | 8 | 10 | 12 | 6 | 8 | 10 | 12 | 6 | 8 | 10 | 12 | 6 | 8 | 10 | 12 |
| 4 | 7 | 94.5 | 70.9 | 57 | 47.2 | 2 | 78.7 | 59 | 47.2 | 39.4 | 2 | 67.5 | 50.6 | 40.5 | 33.7 | 2 | 59 | 44 | 35 | 29.5 | 2 |
| 5 | 14 | 185 | 139 | 111 | 92.5 | 2 | 154 | 116 | 92.5 | 77.1 | 2 | 132 | 99.1 | 79.3 | 66.1 | 2 | 116 | 86.7 | 69.4 | 57.8 | |
| 6 | 21 | 274 | 205 | 164 | 137 | C1 | 228 | 171 | 137 | 114 | C1 | 196 | 147 | 117 | 97.8 | C1 | 171 | 128 | 103 | 85.5 | C1 |
| 7 | 27 | 363 | 273 | 218 | 182 | C2 | 303 | 227 | 182 | 151 | C2 | 260 | 195 | 156 | 130 | C2 | 227 | 170 | 136 | 114 | C2 |
| 8 | 34 | 456 | 342 | 274 | 228 | C2 | 380 | 285 | 228 | 190 | C2 | 326 | 244 | 196 | 163 | C2 | 285 | 214 | 171 | 143 | C2 |
| 9 | 42 | 554 | 415 | 332 | 277 | | 462 | 346 | 277 | 231 | | 396 | 297 | 237 | 198 | | 346 | 260 | 208 | 173 | |
| 10 | 49 | 658 | 494 | 395 | 329 | | 548 | 411 | 329 | 274 | | 470 | 353 | 282 | 235 | | 411 | 308 | 247 | 206 | |
| 11 | 58 | 769 | 577 | 462 | 385 | 3 | 641 | 481 | 385 | 321 | 3 | 550 | 412 | 330 | 275 | 3 | 481 | 361 | 289 | 240 | 3 |
| 12 | 67 | 889 | 667 | 533 | 444 | C1 | 741 | 555 | 444 | 370 | C1 | 635 | 476 | 381 | 317 | C1 | 555 | 417 | 333 | 278 | C1 |
| 13 | 76 | 1016 | 762 | 610 | 508 | C1 | 847 | 635 | 508 | 423 | C1 | 726 | 544 | 435 | 363 | C1 | 635 | 476 | 381 | 317 | C1 |
| 14 | 86 | 1151 | 863 | 691 | 576 | C2 | 959 | 719 | 576 | 480 | C2 | 822 | 617 | 493 | 411 | C2 | 719 | 540 | 432 | 360 | C2 |
| 15 | 97 | 1293 | 970 | 776 | 647 | | 1078 | 808 | 647 | 539 | | 924 | 693 | 554 | 462 | | 808 | 666 | 485 | 404 | |
| 16 | 108 | 1441 | 1081 | 865 | 721 | 4 | 1201 | 901 | 721 | 600 | 4 | 1029 | 772 | 618 | 515 | 4 | 901 | 676 | 540 | 450 | 4 |
| 17 | 120 | 1594 | 1195 | 956 | 797 | | 1328 | 996 | 797 | 664 | | 1138 | 854 | 683 | 569 | | 996 | 747 | 598 | 498 | |
| 18 | 131 | 1749 | 1311 | 1049 | 874 | C1 | 1457 | 1093 | 874 | 729 | C1 | 1249 | 937 | 749 | 625 | C1 | 1093 | 820 | 656 | 546 | C1 |
| 19 | 143 | 1904 | 1428 | 1142 | 952 | C1 | 1587 | 1190 | 952 | 793 | C1 | 1360 | 1020 | 816 | 680 | C1 | 1190 | 892 | 714 | 595 | C1 |
| 20 | 154 | 2056 | 1542 | 1234 | 1028 | C1 | 1714 | 1285 | 1028 | 857 | C1 | 1469 | 1102 | 881 | 734 | C1 | 1285 | 964 | 771 | 643 | C1 |

| | | D-903 PLUS | | | | | | | | | | | | TABLE 1 | | | | | | | |
|----|---------------|------------|------|------|------|-------|---|----|----|-------|------|------|------|---------|---|----|----|---|---|----|----|
| | | 30 m | | | | 36 m | | | | Kg/Ha | | | | | | | | | | | |
| | Kg/min | Kg/Ha | | | | Kg/Ha | | | | Km/h | | | | Km/h | | | | | | | |
| | | 6 | 8 | 10 | 12 | 6 | 8 | 10 | 12 | 6 | 8 | 10 | 12 | 6 | 8 | 10 | 12 | 6 | 8 | 10 | 12 |
| 4 | 7 | 47.2 | 35.4 | 28 | 23.6 | | | | | 39.4 | 29.5 | 23.6 | 19.7 | | | | | | | | |
| 5 | 14 | 92.5 | 69.4 | 55.5 | 46.2 | | | | | 77.1 | 57.8 | 46.2 | 38.5 | | | | | | | | |
| 6 | 21 | 137 | 103 | 82.1 | 68.4 | | | | | 114 | 85.5 | 68.4 | 57 | | | | | | | | |
| 7 | 27 | 182 | 136 | 109 | 90.9 | | | | | 151 | 114 | 90.9 | 75.7 | | | | | | | | |
| 8 | 34 | 228 | 171 | 137 | 114 | | | | | 190 | 143 | 114 | 95 | | | | | | | | |
| 9 | 42 | 277 | 208 | 166 | 138 | | | | | 231 | 173 | 138 | 115 | | | | | | | | |
| 10 | 49 | 329 | 247 | 197 | 165 | | | | | 274 | 206 | 165 | 137 | | | | | | | | |
| 11 | 58 | 385 | 289 | 231 | 192 | | | | | 321 | 240 | 192 | 160 | | | | | | | | |
| 12 | 67 | 444 | 333 | 267 | 222 | | | | | 370 | 278 | 222 | 185 | | | | | | | | |
| 13 | 76 | 508 | 381 | 305 | 254 | | | | | 423 | 317 | 254 | 212 | | | | | | | | |
| 14 | 86 | 576 | 432 | 345 | 288 | | | | | 480 | 360 | 288 | 240 | | | | | | | | |
| 15 | 97 | 647 | 485 | 388 | 323 | | | | | 539 | 404 | 323 | 269 | | | | | | | | |
| 16 | 108 | 721 | 540 | 432 | 360 | | | | | 600 | 450 | 360 | 300 | | | | | | | | |
| 17 | 120 | 797 | 598 | 478 | 398 | | | | | 664 | 498 | 398 | 332 | | | | | | | | |
| 18 | 131 | 874 | 656 | 525 | 437 | | | | | 729 | 546 | 437 | 364 | | | | | | | | |
| 19 | 143 | 952 | 714 | 571 | 476 | | | | | 793 | 595 | 476 | 397 | | | | | | | | |
| 20 | 154 | 1028 | 771 | 617 | 514 | | | | | 857 | 643 | 514 | 428 | | | | | | | | |

13. ASSEMBLING THE CONVERSION KIT FROM 24M TO 30-36 M IN MODEL D-903




Fig. 36




Fig. 37

THE KIT CONTAINS:

- 1 RIGHT CENTRIFUGAL DISC WITH ASSEMBLED SHORT AND LONG SPREADING VANES.
- 1 LEFT CENTRIFUGAL DISC WITH ASSEMBLED SHORT AND LONG SPREADING VANES.
- 1 RIGHT FUNNEL.
- 1 LEFT FUNNEL.
- 1 EXTENSION FOR THE RIGHT FUNNEL.
- 1 EXTENSION FOR THE LEFT FUNNEL.
- 2 OUTLET OPENINGS' GUIDE SPACER RINGS.
- 2 HALF SPHERES FOR DISC'S SUPPORT.
- 2 M-8 X 20 INOX SCREWS WITH SELF-LOCKING NUTS.

THE FOLLOWING TOOLS ARE REQUIRED:

- 2 OPEN-ENDED SPANNERS, NOMINAL SIZE 12-13
- 1 OPEN-ENDED SPANNER, NOMINAL SIZE 16-17
- 1 CYLINDRICAL DRIFT PUNCH, 4 MM DIAMETER AND A HAMMER
- 1 VICE.

The D-903 fertiliser spreader can work at 30-36 m working width if some elements of the machine are replaced with those supplied in the 24-30 m and 36 m conversion kit.

With the spreader empty, loosen the screws that fix the funnel support and the adapter fastening screw (Fig. 36).

First of all remove both the funnel adaptor and the adaptor for 24 m, and then free the locking pin in order to remove the 24 m funnel and replace it with the 30-36 m one that matches its orientation (at the end of its shaft, funnels have a D (Right) or a l (Left) inscribed, meaning Right or Left orientation).

Next, put away the adaptor for 24 metres since it is not required in the 30-36m machine.

Remove the spreading disc using the four M-10 round head screws that fix it to its support, place the half sphere on the spreading disc's support and, then, the disc with spreading vanes for 30-36 metres of the same orientation. Next, fix the disc back using the four round-head screws.

Place the funnel's extension under the outlet opening and then place the outlet opening guide's spacer ring (Fig. 37) as well as the M-8 x 20 screw of the front part along with its self-locking nut.

The funnel's support with the funnel for 30-36 metres must be placed in the two rearmost holes which correspond, as shown in the figure (fig. 2) to the 36 metres position. The foremost holes (in which the funnel's support was previously placed) are used to work with the funnel for 24 m.

Once the funnel's support is placed under the sheet of the funnel's extension, the M-8 screw needs to be screwed from below upwards passing first through the funnel's support, the funnel's extension, the outlet and, finally, the hopper's bottom sheet. Firstly the nut needs to be screwed until the end of the thread and, then unscrewed slowly until the trapdoor can be opened and closed (this screw works as a joint).

These operations need to be performed in both sides of the machine. Check that the funnels are correctly assembled and they do not show contact to the disc's spreading vanes at any position when the spreading disc turns.

Before starting to work, the machine needs to be adjusted as shown in the tables for 30-36 metres.

14. ASSEMBLING THE CONVERSION KIT FROM 30-36 M TO 24 M IN MODEL D-903 PLUS




Fig. 38

THE KIT CONTAINS:

- 1 RIGHT CENTRIFUGAL DISC WITH THREE ASSEMBLED RIGHT SPREADING VANES.
- 1 LEFT CENTRIFUGAL DISC WITH THREE ASSEMBLED LEFT SPREADING VANES.
- 1 RIGHT FUNNEL (INSCRIBED WITH A D IN THE SHAFT'S END)
- 1 LEFT FUNNEL (INSCRIBED WITH A L IN THE SHAFT'S END)
- 2 ADAPTORS FOR 24 METRES.
- 2 M-8 X 25 INOX SCREWS WITH SELF-LOCKING NUTS.
- 2 ROUND CAPS FOR THE SPREADING DISC'S SUPPORT.

THE FOLLOWING TOOLS ARE REQUIRED:

- 2 OPEN-ENDED SPANNERS OF NOMINAL SIZE 12-13
- 1 OPEN-ENDED SPANNER OF NOMINAL SIZE 16-17
- 1 CYLINDRIC DRIFT PUNCH OF 4 MM DIAMETER AND A HAMMER
- 1 VICE (IF POSSIBLE)

Fertiliser spreader **D-903** provides the possibility of work at 15-24 m of working width by replacing some elements of the machine with the ones supplied in the conversion kit from 30-36 m to 24 m. The fertiliser spreader must be empty to perform this operation. First of all, unscrew the 4 screws that fix the funnel's support and the funnel's extension (Fig. 38).

First of all, remove the funnel's extension, the guide spacer ring (not required when working at 15-24 m) and the funnel's support along with the funnel (Fig. 38).

Next, free the locking pin of the funnel in order to replace it with the one for 24 m that matches the same orientation.

Remove the disc using the four M-10 round head screws that fix it to the spreading disc's support and remove the half sphere since it is not required in the machine of 15-24 m (Fig. 38).

Before placing the disc of 15-24 m that matches the same orientation, place the end-piece / cap on the spreading disc's support (Fig. 39).

Next, place the disc with the three spreading vanes and fix the disc back using the four M-10 round head screws (Fig. 39).

Fix the funnel's support using the two screws from the exterior part in the position corresponding to 24 m, as shown in figure 39.

Place the adaptor for 24 m under the funnel's support with the pin upwards and inside the support's hole which is now free.

Next, the M-8x25 inox screw needs to be screwed from below upwards so that fixes the adaptor, operates as a joint for the fertiliser's outlet opening and goes through the hopper's bottom sheet, as is shown in the centre of figure 39.

Then, the self-locking nut needs to be firstly tightened until the end of the thread and, then loosened slowly until the outlet opening can be opened and closed.

These operations need to be performed in both sides of the machine. Check that the funnels are correctly assembled and they do not show contact to the disc's spreading vanes at any position when the disc turns manually.

Before starting to work, the machine needs to be adjusted as shown in the tables for 15-24 metres.





Fig. 39

15. SPARE PARTS

The terms **RIGHT, LEFT, FRONT and REAR** refer to the machine in its drive direction, as shown in the figure below.

When guidance describes parts that have a matching pair (symmetrical handles, wheels etc) only one will be demonstrated in the drawings shown. Please search for the distinguishing reference in the spare parts list.




WHEN ORDERING SPARE PARTS TO SOLÁ, PLEASE INDICATE NUMBER AND TYPE OF THE MACHINE AS SHOWN IN THE IDENTIFICATION PLATE WHICH CAN BE FOUND AT THE RIGHT REAR PART THE HOPPER.



AS A GENERAL RULE, DO NOT WORK UNDER THE MACHINE WHEN IT IS RAISED. IF SUCH A WORK IS REQUIRED, ALWAYS SECURE THE MACHINE PROPERLY TO PREVENT IT FROM COLLAPSING AS A PRESSURE LOSS IN THE TRACTOR CAN OCCUR.


15.1 CHASSIS D-903 : D-903 PLUS

| Nº | REFERENCE | DESCRIPTION |
|----|-----------------|--|
| 1 | PS-015107 | CHASIS ABONADORA D-903 (PUNTEAR) |
| 1 | PS-015108 | CHASIS ABONADORA D-903 (SOLDAR) |
| 2 | CN-817000 | CONTERA PARA VARILLA DE Ø 12 |
| 3 | B03-143 | BULON CILINDRO MANDO HD. |
| 4 | 94 3,2X20 BI | PASADOR ALETAS DIN 94 M 3,2X20 BICROMATADO |
| 5 | ML-015101 | MUELLE DEL PIE |
| 6 | 94 5X32 BI | PASADOR ALETAS DIN 94 M 5X32 BICROMATADO |
| 7 | BU-080206 | BULON Ø 16X37 ESTAMPADO |
| 8 | PS-015100 | BULON ENGANCHE ABONADORAS |
| 9 | PS-2105/D | PIE DESCANSO DER. |
| 9 | PS-2105/I | PIE DESCANSO IZQ. |
| 10 | PS-010101 | BULON DEL TRIPODE |
| 11 | PS-045127 | PROTECTOR TOMA DE FUERZA AB. D-5/R |
| 12 | 125 20 BI | ARANDELA PLANA DIN 125 M 20 BICROMATADA |
| 13 | PS-015112 | SUJECCIÓN CAJA CENTRAL |
| 14 | 933 8X20 | TORNILLO DIN 933 M 8x20 |
| 15 | ML-015100 | MUELLE GATILLO SUJECCION TOLVA |
| 16 | EE-025102 | GATILLO SUJECCION TOLVA |
| 17 | 94 3,5X28 BI | PASADOR ALETAS DIN 94 M 3,5X28 BICROMATADO |
| 18 | FE-610008 | PASADOR DE ANILLA BICROM. |
| 19 | 985 8 I | TUERCA DIN 985 M 8 INOX. |
| 20 | 931 8X45 I | TORNILLO DIN 931 M 8X45 INOX. |
| 21 | PX-045152/D | PROTECTOR INOX. DISCO DER. |
| 22 | PX-045152/I | PROTECTOR INOX. DISCO IZQ. |
| 23 | 933 8X15 I | TORNILLO DIN 933 M 8X15 INOX. |
| 24 | 933 12X20 8.8 B | TONILLO DIN 933 M 12X20 8.8 BICROMATADO |
| 24 | 933 12X30 8.8 B | TORNILLO DIN 933 M 12X30 8.8 BICROMATADO |
| 25 | 934 12 BI | TUERCA DIN 934 M 12 BICROMATADO |
| 26 | 94 5X25 BI | PASADOR ALETAS DIN 94 M 5X25 BICROMATADO |




15.2 FRONTAL FRAME D-903/3000 : D-903 PLUS/3000

| Nº | REFERENCE | DESCRIPTION |
|-----------|--------------|--|
| 1 | PS-014100 | CHASIS REMOLQUE AB. D-903/3000 |
| 2 | PS-2181 | EXCENTRICA LARGA FRENO |
| 3 | FE-600024 | RODAMIENTO 6007 2RS |
| 4 | ME-044100 | EJE UNIÓN TRANSMISIÓN CARDAN |
| 5 | 471 35 | ANILLO SAEGER DIN 471M 35 |
| 6 | B01-39 | BIELA LARGA FRENO EST. |
| 7 | 94 3.5x20 BI | PASADOR ALETAS DIN 94 3.5X20 BICROMATADO |
| 8 | 125 14 BI | ARANDELA DIN 125 M 14 BICROMATADA |
| 9 | 125 24 BI | ARANDELA DIN 125 M 24 BICROMATADA |
| 10 | 94 5x36 BI | PASADOR ALETAS DIN 94 M 5X36 BICROMATADO |
| 11 | PP-71 | PALANCA FRENO ESTACIONAMIENTO |
| 12 | A01-16 | ANILLO TOPE BRAZO RASTRILLO |
| 13 | 985 14 | TUERCA DIN 985 M 14 BICROMATADA |
| 14 | 931 16X110 | TORNILLO DIN 931 M 16X110 BICROMATADO |
| 15 | P03-230 | PLETINA BRIDA SUJECIÓN CHASIS A EJE |
| 16 | 985 16 | TUERCA DIN 985 M 16 BICROMATADA |
| 17 | 931 14X130 | TORNILLO DIN 931 M 14X130 BICROMATADO |
| 18 | 472 62 | ANILLO SAEGER DIN 472M 62 |




15.3 FRONTAL FRAME COMPL. D-903/3000 : D-903 PLUS/3000

| Nº | REFERENCE | DESCRIPTION | Nº | REFERENCE | DESCRIPTION |
|----|------------------|--|----|-----------------|---|
| 1 | PR-014101 | SOPORTE TRASERO TOLVA | 31 | 1481 8x50 BI | PASADOR ELÁSTICO DIN 1481 BICROMATADO |
| 2 | PS-074100 | EJE REMOLQUE ABONADORA D-903/3000 | 32 | T06-35 | TOPE HUSILLO PIE |
| 3 | PS-074101 | RASCADOR AB. D-903/3000 | 33 | 931 10x55 8.8 B | TORNILLO DIN 931 M 10X55 8.8 BICROMATADO |
| 4 | PS-014103 | TIRANTE TRÍPODE | 34 | FE-610008 | PASADOR DE ANILLA . Ø 11 BICROMATADO |
| 5 | PS-015202 | BULÓN DESCANSO PIE | 35 | B03-197 | BULÓN Ø 25 X 100 |
| 6 | PS-2179 | TUBO EXTERIOR PIE | 36 | PX-044101 | PROTECTOR LARGO T.D.F. |
| 7 | PS-2155 | TUBO INTERIOR PIE | 37 | PX-044100 | PROTECTOR T.D.F. |
| 8 | PS-015201 | HUSILLO PIE | 38 | 931 10X115 8.8B | TORNILLO DIN 931 M 10X115 8.8 BICROMATADO |
| 9 | PS-2180 | VARILLA TENSORA FRENO | 39 | 94 5x40 BI | PASADOR ALETAS DIN 94 M 5X40 BICROMATADO |
| 10 | PS-2151 | CORREDERA POLEA FRENO | 40 | FE-610004 | PASADOR "R" BICROMATADO |
| 11 | PS-074102 | ESCALERA AB. D-903/3000 | 41 | B03-198 | BULÓN Ø 25 X 93 |
| 12 | PS-2150 | ENGANCHE | 42 | B10-21 | BRIDA SUJECCION CILINDRO |
| 13 | PL-045201 | CAMARA PARA 12,5-80-15,3 | 43 | 985 8 | TUERCA AUTOBLOCANTE DIN 985 M 8 BICROMATADA |
| 14 | 933 14X40 8.8 B | TORNILLO DIN 933 M 14X40 8.8 BICROMATADO | 44 | CO-045101 | CILINDRO S.E.MANDO HIDRÁULICO |
| 15 | 931 14X130 8.8 B | TORNILLO DIN 931 M 14X130 8.8 BICROMATADO | 45 | 933 10X50 8.8 B | TORNILLO DIN 933 M 10X50 8.8 BICROMATADO |
| 16 | 125 14 BI | ARANDELA DIN 125 M 14 BICROMATADA | 46 | VA-075201 | CABLE FRENO |
| 17 | 985 14 | TUERCA AUTOBLOCANTE DIN 985 M 14 BICROMATADA | 47 | FE-608015 | TRANS.CARDAN L=1000 2002/1000/KH/19.1/19.1 |
| 18 | CO-045200 | RUEDA COMPLETA 12,5-80-15,3 14 PR | 48 | FE-650012 | PRENSACABLES ESTAMPADO |
| 19 | 931 12X90 8.8 B | TORNILLO DIN 931 M 12X90 8.8 BICROMATADO | 49 | HI-700029 | TUBO R2AT 1/4" L=2,5 M TL 1/4"-M 1/2" |
| 20 | 985 12 | TUERCA AUTOBLOCANTE DIN 985 M 12 BICROMATADA | 50 | HI-705002 | ARANDELA METALBUNA 1/2" GAS |
| 21 | CN-817022 | TAPÓN OBTURACIÓN P/AGUJERO Ø10.5X3 | 51 | HI-701000 | ENCHUFE RAPIDO 1/2""FASTER" |
| 22 | 125 10 BI | ARANDELA DIN 125 M 10 BICROMATADA | 52 | HI-707001 | TAPÓN ENCHUFE RAPIDO |
| 23 | 985 10 | TUERCA AUTOBLOCANTE DIN 985 M 10 BICROMATADA | 53 | AD-075201 | PLACA IDENTIFICACION ABONADORAS ARRSTRADAS |
| 24 | 94 5x25 BI | PASADOR ALETAS DIN 94 M 5X25 BICROMATADO | 54 | FE-602001 | REMACHE ALUMINIO |
| 25 | 125 16 BI | ARANDELA DIN 125 M 16 BICROMATADA | 55 | 931 14X90 BI | TORNILLO DIN 931 M 14X90 8.8 BICROMATADO |
| 26 | P03-36 | POLEA CABLE FRENO | 56 | PL-045200 | NEUMÁTICO 12,5-80-15,3 SIN CAMARA |
| 27 | 931 10X45 I | TORNILLO DIN 931 M 10X45 INOX | 57 | CO-045201 | RUEDA METÁLICA |
| 28 | 1481 5x50 BI | PASADOR ELÁSTICO DIN 1481 BICROMATADO | | | |
| 29 | 985 16 | TUERCA AUTOBLOCANTE DIN 985 M 16 BICROMATADA | | | |
| 30 | 933 16X50 8.8 B | TORNILLO DIN 933 M 16X50 8.8 BICROMATADO | | | |




15.4 FERTILIZER FENDERS D-903/3000

| Nº | REFERENCE | DESCRIPTION |
|----|----------------|---|
| 1 | PS-074105/D | CHAPA GUARDABARROS DER. AB. D-903/3000 |
| 1 | PS-074105/I | CHAPA GUARDABARROS IZQ. AB. D-903/3000 |
| 2 | PS-074103/D | SOPORTE TRASERO GUARDABARROS DER. |
| 2 | PS-074103/I | SOPORTE TRASERO GUARDABARROS IZQ. |
| 3 | PS-074104/D | SOPORTE DEL. DER. GUARDABARROS |
| 3 | PS-074104/I | SOPORTE DEL. IZQ. GUARDABARROS |
| 4 | PS-074101 | RASCADOR ABONADORA D-903/3000 |
| 5 | PX-062105 | BRIDA TUBO 60 |
| 6 | EE-053111 | BRIDA TUBO 60 M12x108 EUROPA 2000 N/XS |
| 7 | 985 8 B | TUERCA DIN 985 M-8 BICROMATADA |
| 8 | 931 8X30 8.8 B | TORNILLO DIN 931 M-8X30 8.8 BICROMATADO |
| 9 | 985 12 B | TUERCA DIN 985 M-12 BICROMATADA |
| 10 | 931 8X40 8.8 B | TORNILLO DIN 931 M-8X40 8.8 BICROMATADO |



15.5 FERTILIZER HOPPER D-903 Y D-903 PLUS


| Nº | REFERENCE | DESCRIPTION |
|-----------|--------------|---|
| 1 | PS-2109 | ÁNGULO DESCANSO TOLVA |
| 2 | PS-2108 | «U» ARTICULACIÓN TOLVA |
| 3 | 127 5 BI | DIN 127 M 5 BI |
| 4 | RE-025101 | ALZA 200 L ABONADORA D-5 CON TORNILLERIA |
| 4 | RE-025102 | ALZA 500 L ABONADORA D-5 CON TORNILLERIA |
| 4 | VA-075100 | ALZA DE 1000L. COMPLETA |
| 5 | PS-035106 | CRIBA INCLINADA |
| 6 | CN-817002 | CONTERA REDONDA PARA TUBO Ø 32x2 |
| 7 | PS-025100 | TOLVA ABONADORA |
| 8 | PX-105100 | PLETINA PORTALUCES |
| 9 | CN-818009 | LUCES D-903 |
| 10 | PX-045136 | CANAL PARA PRUEBAS DE CAUDAL |
| 11 | AD-070228 | ADHESIVO SOLA 455X77 455X77 MM |
| 12 | AD-075111 | ADHESIVO D-903 |
| 13 | AD-075112 | ADHESIVO D-903 PLUS |
| 14 | PS-075102 | PROTECCIÓN ABONADORA D-903 ; D-903 PLUS |
| 15 | CN-818019 | CATADIÓPTRICO REFLECTANTE ROJO TRIANGULAR |
| 16 | 7985 5X15 BI | TORNILLO DIN 7985 M 5X15 BICROMATADO |
| 17 | 934 5 BI | TUERCA DIN 934 M 5 BICROMATADA |



15.6 REGULATION, DISTRIBUTION AND TRANSMITION D-903 PLUS

| Nº | REFERENCE | DESCRIPTION |
|----|---------------|------------------------------------|
| 1 | ME-045145 | PIÑÓN 1/2=39Z TRANS. AGITADOR |
| 2 | FE-605028 | CADENA 1/2 TRANS. AGITADOR |
| 3 | FE-600029 | RODAMIENTO 1025 C/SOPORTE |
| 4 | ME-045146 | EJE TRANS. AGITADOR (BICROM.) |
| 5 | FE-601013 | RETEL DOBLE LABIO Ø18X30X7 |
| 6 | FE-600030 | CASQUILLO FRICCIÓN 18X20X22 C/VAL. |
| 7 | 471 25 | ANILLO SAEGER P/EJE DIN 471 Ø25 |
| 8 | 985 81 | TUERCA DIN 985 M8 INOX |
| 9 | 933 8X35 I | TORNILLO DIN 933 M8X35 INOX |
| 10 | 6885-A 8X7X28 | CHAVETA DIN 6885 FORMA A 8X7X28 |
| 11 | TA-045114/D | DISCO CENTRIFUGO DER. |
| 12 | PX-045138/D | PALA CORTA DER. |
| 13 | PX-045139/D | EXTENSIÓN PALA CORTA DER. |
| 14 | PX-045110/D | TRAMPILLA CONTR. SAL. ABONO DER. |
| 15 | PX-045110/I | TRAMPILLA CONTR. SAL. ABONO IZQ. |
| 16 | TA-045114/I | DISCO CENTRIFUGO IZQ. |
| 17 | FE-609009 | RUEDA TENSORA 16Z -1/2 |
| 18 | EE-030200 | ARANDELA Ø 30X8.5X3 Zn |
| 19 | BU-040500 | BULÓN ROSCADO DEL PIÑÓN DESVIADOR |
| 20 | ML-041100 | MUELLE TENSOR CADENA TRANS. |
| 21 | PX-015112 | PROTECTOR CADENA TRANSMISIÓN |
| 22 | PX-045145/I | SUPLEMENTO BOQUILLA IZQ. |
| 23 | PX-045141/D | PALA LARGA DER. |
| 24 | PX-045141/I | PALA LARGA IZQ. |
| 25 | PX-045142/D | EXTENSIÓN PALA LARGA DER. |
| 26 | PX-045142/I | EXTENSIÓN PALA LARGA IZQ. |
| 27 | EE-045144 | MEDIA ESFERA CENTRAL DISCO |
| 28 | PL-045107 | COJINETE 25/28/30 NYLON |
| 29 | FE-610001 | HORQUILLA CON BULÓN M-12 |
| 30 | ME-045147 | PIÑÓN 1/2=13Z TRANS. AGITADOR |


| Nº | REFERENCE | DESCRIPTION |
|----|----------------|--------------------------------------|
| 31 | 6885-A 6X6X25 | CHAVETA DIN 6885 FORMA A 6X6X25 |
| 32 | 934 12 BI | TUERCA DIN 934 M-12 BICROM. |
| 33 | 933 8X15 8.8 B | TORNILLO DIN 933 M-8X15 8.8 BICROM. |
| 34 | PL-040204 | TENSOR CADENA |
| 35 | EE-045143 | TORNILLO DIN 603 C/C INOX. |
| 36 | PL-045103 | VOLANTE CON TUERCA M-10 |
| 37 | 933 10X30 8.8B | TORNILLO DIN 933 M 10X30 8.8 BICROM. |
| 38 | 913 10X60 B | TORNILLO DIN 931 M 10X60 BICROM. |
| 39 | 934 10 I | TUERCA DIN 934 M-10 INOX |
| 40 | 603 8X20 I | TORNILLO DIN 603 C/C INOX |
| 41 | PX-045138/I | PALA CORTA IZQ. |
| 42 | PX-045139/I | EXTENSIÓN PALA CORTA IZQ |
| 43 | 315 81 | TUERCA DIN 315 INOX. |
| 44 | ME-045301 | ANILLO SEPARADOR GUÍA TRAMP. |
| 45 | PS-045119/D | FONDO TOLVA DER. AB. D-903 |
| 46 | PS-045119/I | FONDO TOLVA IZQ. AB. D-903 |
| 47 | PS-045126 | AGITADOR ABONADORA D-903 |
| 48 | PS-045130 | SOPORTE BOQUILLA D-903 |
| 49 | PS-045132/D | BOQUILLA DERECHA |
| 50 | PS-045132/I | BOQUILLA IZQUIERDA |
| 51 | ME-045135 | DISCO PORTAPL. AB. D-5 (MECANIZAR) |
| 51 | MO-045104 | DISCO PORTAPL. CON CASQUILLOS |
| 52 | PS-045129 | BRAZO TENSOR CADENA |
| 53 | PS-045134/I | VARILLA IZQ. MANDO TRAMPILLA |
| 54 | PS-045134/D | VARILLA DER. MANDO TRAMPILL |
| 55 | PS-045131 | PALANCA DE LA BOQUILLA |
| 56 | CO-045104 | GRUPO TRIPLE ABONADORA D-903 |
| 57 | MO-045111 | PASADOR DESCONECCIÓN AGITADOR |
| 58 | MO-045116/D/I | PLATO CENTRIF. D/I 36 m.C/ PALAS |
| 59 | PX-015119 | TAPA INSPECCIÓN CADENA AGIT. |
| 60 | PL-073100 | VOLANTE CON TUERCA M-6 |
| 61 | PX-045140/I | PALA FIJA IZQUIERDA |
| 61 | PX-045150/D | PALA FIJA DERECHA |



15.7 REGULATION, DISTR. AND TRANS. D-903 Y D-903/3000


| Nº | REFERENCE | DESCRIPTION |
|----|---------------|------------------------------------|
| 1 | EE-045152/D | VARIILLA DER.CIERRE TRAMPILLA |
| 2 | ME-045145 | PIÑON ½»39Z TRANS. AGITADOR |
| 3 | FE-605028 | CADENA ½» TRANS. AGITADOR |
| 4 | FE-600029 | RODAMIENTO 1025 C/SOPORTE |
| 5 | ME-045146 | EJE TRANS. AGITADOR (BICROM.) |
| 6 | FE-601013 | RETEN DOBLE LABIO Ø18X30X7 |
| 7 | FE-600030 | CASQUILLO FRICCION 18X20X22 C/VAL. |
| 8 | 471 25 | ANILLO SAEGER P/EJE DIN 471 Ø25 |
| 9 | 985 8 I | TUERCA DIN 985 M8 INOX |
| 10 | 933 8X35 I | TORNILLO DIN 933 M8X35 INOX |
| 11 | 6885-A 8X7X28 | CHAVETA DIN 6885 FORMA A 8X7X28 |
| 12 | EE-045138 | DISCO CENTRÍFUGO |
| 13 | CN-817002 | CONTERA REDONDA PARA TUBO Ø 32x2 |
| 14 | PX-045110/I | TRAMPILLA CONTR. SAL. ABONO IZQ. |
| 14 | PX-045110/D | TRAMPILLA CONTR. SAL. ABONO DER. |
| 15 | 315 8 I | TUERCA DIN 315 INOX. |
| 16 | FE-609009 | RUEDA TENSORA 16Z -½» |
| 17 | EE-030200 | ARANDELA Ø 30X8.5X3 Zn |
| 18 | BU-040500 | BULÓN ROSCADO DEL PIÑÓN DESVIADOR |
| 19 | ML-041100 | MUELLE TENSOR CADENA TRANS. |
| 20 | PX-015112 | PROTECTOR CADENA TRANSMISIÓN |
| 21 | EE-045153 | PLETINA CORTA ADAPTADOR 24 m. |
| 22 | EE-045162/I | PALA CENTRÍFUGA /I |
| 23 | EE-045162/D | PALA CENTRÍFUGA /D |
| 24 | PL-045107 | COJINETE 25/28/30 NYLON |
| 25 | FE-610001 | HORQUILLA CON BULÓN M-12 |
| 26 | ME-045147 | PIÑON ½»13Z TRANS. AGITADOR |
| 27 | 6885-A 6X6X25 | CHAVETA DIN 6885 FORMA A 6X6X25 |
| 28 | 125 8 I | ARANDELA DIN 125 Ø8 INOX. |
| 29 | 934 12 BI | TUERCA DIN 934 M-12 BICROM. |

| Nº | REFERENCE | DESCRIPTION |
|----|-----------------|--------------------------------------|
| 30 | 7980 8 I | ARANDELA GROWER DIN 7980 8 INOX |
| 31 | PL-040204 | TENSOR CADENA |
| 32 | EE-045143 | TORNILLO DIN 603 C/C INOX |
| 33 | PL-045103 | VOLANTE CONTUERCA M-10 |
| 34 | 933 8X15 I | TORNILLO DIN 933 M-8X15 INOX |
| 35 | 933 10X30 8.8 B | TORNILLO DIN 931 M 10X30 8.8 BICROM. |
| 36 | 913 10X60 B | TORNILLO DIN 931 M 10X60 BICROM. |
| 37 | 934 10 I | TUERCA DIN 934 M-10 INOX |
| 38 | 7980 10 I | ARANDELA GROWER DIN 7980 INOX |
| 39 | 603 8X20 I C/C | TORNILLO DIN 603 C/C INOX |
| 40 | 934 10 BI | TUERCA DIN 934 M-10 INOX |
| 41 | 7980 10 BI | ARANDELA GROWER DIN 7980 BIC. |
| 42 | 934 12 BI | TURCA DIN 934 M-12 BICROM. |
| 43 | 7980 8 I | ARANDELA GROWER DIN 7980 Ø8 INOX |
| 44 | PS-045119/D | FONDO TOLVA DER. AB. D-5/R |
| 45 | PS-045119/I | FONDO TOLVA IZQ. AB. D-5/R |
| 46 | PS-045126 | AGITADOR ABONADORA D-5/R |
| 47 | PS-045130 | SOPORTE BOQUILLA D-5/R |
| 48 | PS-2118/D | BOQUILLA SALIDA ABONO /D |
| 49 | PS-2118/I | BOQUILLA SALIDA ABONO /I |
| 50 | ME-045135 | DISCO PORTAPL. AB. D-5 (MECANIZAR) |
| 51 | MO-045113 | DISCO PORTAPL. CON CASQ.Y CONT. |
| 51 | PS-045129 | BRAZO TENSOR CADENA |
| 52 | PS-045134/I | VARILLA IZQ. MANDO TRAMPILLA |
| 53 | PS-045134/D | VARILLA DER. MANDO TRAMPILLA |
| 54 | PS-045131 | PALANCA DE LA BOQUILLA |
| 55 | PS-045136 | ADAPTADOR PARA 24 m. |
| 56 | CO-045104 | GRUPO TRIPLE ABONADORA D-903 |
| 57 | MO-045111 | PASADOR DESCONECCIÓN AGITADOR |
| 58 | MO-2107/D/I | PLATO CENTRÍFUGO CON PALAS D/I 24 m. |
| 59 | PX-015119 | TAPA INSPECCIÓN CADENA AGIT. |
| 60 | PL-073100 | VOLANTE CONTUERCA M-6 |




15.8 CONVERSION KIT 36 TO 24 METERS

| Nº | REFERENCE | DESCRIPTION |
|-----------|----------------|-------------------------------------|
| 1 | PS-2118/D | BOQUILLA SALIDA ABONO /D |
| 2 | PS-2118/I | BOQUILLA SALIDA ABONO /I |
| 3 | PS-045136 | ADAPTADOR 24 MTS. |
| 4 | MO-2107/D | PLATO CENTRIFUGO CON PALAS D. 24 m. |
| 5 | MO-2107/I | PLATO CENTRIFUGO CON PALAS I. 24 m. |
| 6 | 985 8 I | TUERCA DIN 985 INOX |
| 7 | 933 8X25 I | TORNILLO DIN 933 M8X25 INOX |
| 8 | 603 8X20 I C/C | TORNILLO DIN 603 C/C INOX. |
| 9 | CN-817002 | CONTERA REDONDA PARA TUBO Ø 32x2 |
| 10 | 315 8 I | TUERCA DIN 315 INOX. |
| 11 | 7980 8 I | ARANDELA GROWER DIN 7980 Ø8 INOX |
| 12 | 125 8 I | ARANDELA DIN 125 Ø8 INOX. |
| 13 | EE-045162/D | PALA CENTRÍFUGA /D |
| 14 | EE-045162/I | PALA CENTRÍFUGA /I |




15.9 CONVERSION KIT 24 TO 36 METERS

| Nº | REFERENCE | DESCRIPTION |
|-----------|----------------|----------------------------------|
| 1 | PS-045132/D | BOQUILLA DERECHA |
| 2 | PS-045132/I | BOQUILLA IZQUIERDA |
| 3 | MO-045116/D | PLATO CENTRIF. D. 36 m.C/ PALAS |
| 4 | MO-045116/I | PLATO CENTRIF. D. 36 m.C/ PALAS |
| 5 | PX-045141/D | PALA LARGA DER. |
| 6 | PX-045142/D | EXTENSIÓN PALA LARGA DER. |
| 7 | PX-045141/I | PALA LARGA IZQ. |
| 8 | PX-045142/I | EXTENSIÓN PALA LARGA IZQ. |
| 9 | PX-045138/I | PALA CORTA IZQ. |
| 10 | PX-045139/I | EXTENSIÓN PALA CORTA IZQ |
| 11 | PX-045138/D | PALA CORTA DER. |
| 12 | PX-045139/D | EXTENSIÓN PALA CORTA DER. |
| 13 | EE-045144 | MEDIA ESFERA CENTRAL DISCO |
| 14 | PX-045145/I | SUPLEMENTO BOQUILLA IZQ. |
| 15 | 985 8 I | TUERCA DIN 985 M8 INOX |
| 16 | 933 8X20 I | TORNILLO DIN 933 M8X20 INOX |
| 17 | 603 8X20 I C/C | TORNILLO DIN 603 C/C INOX. |
| 18 | 125 8 I | ARANDELA DIN 125 Ø8 INOX. |
| 19 | 7980 8 I | ARANDELA GROWER DIN 7980 Ø8 INOX |
| 20 | 315 8 I | TUERCA DIN 315 INOX. |
| 21 | ME-045301 | ANILLO SEPARADOR GUÍA TRAMP. |




15.10 HYDRAULIC CONTROL FERTILIZER D-903 Y D-903 PLUS

| Nº | REFERENCE | DESCRIPTION |
|----|-------------|---------------------------------------|
| 1 | CO-045101 | CILINDRO S.E. MANDO HIDRÁULICO |
| 2 | PL-045101 | MUELLE PROTECTOR CILINDRO |
| 3 | PL-050207 | CASQUILLO ARTICULACIÓN BRAZO |
| 4 | 125 20 BI | ARANDELA PLANA DIN 125 BICROM. |
| 5 | TA-045115 | VÁLVULA 1/4" DOS VÍAS PARA ATORNILLAR |
| 6 | HI-704003 | RACOR CODO M1/4-TL-1/4 |
| 7 | HI-706009 | VÁLVULA 1/4"-MF1/4"IZQ.-HF1/4"DER. |
| 8 | HI-705001 | ARANDELA METALBUNA 1/4"GAS |
| 9 | HI-704000 | RACOR M1/4"-HG1/4" |
| 10 | HI-703004 | RACORT MF1/4-MF1/4-MF1/4 |
| 11 | HI-700046 | TUBO R2 AT 1/4";TL1/4";CODO 90°TL1/4" |
| 12 | HI-700045 | TUBO R2 AT 1/4";TL1/4";CODO 90°TL1/4" |
| 13 | HI-700066 | TUBO R2 AT 1/4";TL1/4";TL1/4" |
| 13 | HI-700081 | TUBO R2AT 1/4" L=3,5M TL1/4"-TL1/4" |
| 14 | 94 5X40 BI | PASADOR ALETAS DIN 94 BI |
| 15 | HI-704008 | RACOR M1/2"- M1/4" |
| 16 | HI-705002 | ARANDELA METALBUNA 1/2"GAS |
| 17 | HI-707001 | TAPÓN ENCHUFE RÁPIDO |
| 18 | HI-701000 | ENCHUFE RÁPIDO 1/2" «FASTER» |
| 19 | AD-045100 | ADHESIVO GRADUADOR O-20 |
| 20 | PS-045128 | GRADUADOR CON SOPORTE MANDO HID. |
| 21 | PS-045133/D | PALANCA DER. MANDO HID. |
| 22 | PS-045133/I | PALANCA IZQ. MANDO HID. |
| 23 | PS-045110 | TOPE PALANCA DERECHA |
| 24 | PS-045407 | MANIVELA TOPE PALANCA |




15.11 SHORT LIMITER (MECH.L/HYDRAULIC) D-903 Y D-903 PLUS

| Nº | REFERENCE | DESCRIPTION |
|-----------|--------------|--|
| 1 | PX-045148 | BIELA LIMITADOR ORILLAS |
| 2 | BU-100204 | BULÓN ROSCADO DEL CILINDRO |
| 3 | FE-610002 | PASADOR «R» DE 3 MM. |
| 4 | FE-603001 | ENGRASADOR RECTO M-6 |
| 5 | 94 3.5X28 BI | PASADOR ALETAS DIN 90 BICROM. |
| 6 | CO-100201 | CILINDRO DEL VARIADOR |
| 7 | ME-045153 | CONTRATUERCA TOPE CILIND. LIMITADOR HIDR. |
| 7 | ME-045154 | CONTRATUERCA TOPE CILIND. LIMITADOR HIDR. PLUS |
| 8 | PL-045104 | FUELLE PROTECTOR CILINDRO LIMITADOR |
| 9 | ME-100210 | ESTRANGULADOR CILINDRO TRAZADORES |
| 10 | HI-705001 | ARANDELA METALBUNA 1/4" GAS |
| 11 | ME-100212 | TORNILLO SIMPLE 1/4" GAS CON ENTALLA |
| 12 | HI-704010 | RACOR M-1/4 M-1/4 |
| 13 | HI-704000 | RACOR UNIÓN MF1/4-HG1/4 |
| 14 | HI-706005 | VÁLVULA SELECTORA 1/4"VFC -NC |
| 15 | HI-706012 | VÁLVULA ANTIRRETORNO PIL. S.E.F. 1/4" |
| 16 | HI-700044 | TUBO R2-AT 1/4 L=1.22M.E1/4-TL1/4 |
| 17 | HI-700074 | TUBO R2-AT 1/4 L=1.3M.TL1/4-M1/4 |
| 18 | HI-700075 | TUBO R2-AT 1/4 L=0.5M. M1/4-M1/2 |
| 19 | HI-705002 | ARANDELA METALBUNA 1/2" |
| 20 | HI-701000 | ENCHUFE RÁPIDO 1/2" |
| 21 | HI-707001 | TAPÓN ENCHUFE RÁPIDO |
| 22 | HI-704008 | RACOR UNIÓN MF1/4"-MF1/2" |
| 23 | HI-703004 | RACORT MF1/4-MF1/4-MF1/4 |
| 24 | PS-045137 | SOPORTE LIMITADOR ORILLAS |
| 25 | PS-045138 | PANTALLA LIMITADORA DE ORILLAS |
| 26 | PS-045139 | ART. CABEZA CILINDRO LIMITADOR |
| 26 | EO-105104 | LIMITADOR HIDRÁULICO PARA ORILLAS D-903 |
| 26 | EO-105105 | LIMITADOR HIDRÁULICO PARA ORILLAS D-903 PLUS |




15.12 SHORT LIMITER D-903/3000; D-903 PLUS/3000

| Nº | REFERENCE | DESCRIPTION |
|----|-----------------|--|
| 1 | PS-044101 | SOPORTE PANTALLA LIMIT. AB. D-903/3000 |
| 2 | PS-044100 | PANTALLA LIMITADORA AB. D-903/3000 |
| 3 | 931 10x70 8.8 B | TORNILLO DIN 931 M10X70 8.8 BICROM. |
| 4 | 985 10 BI | TUERCA DIN 985 M10 BICROM. |
| 5 | FE-610002 | CLIP R DE 3 BICROM. |




15.13 TRANSMITION

| Nº | REFERENCE | DESCRIPTION |
|-----------|-------------|----------------------------|
| 1 | ME-045155 | CARCASA AB.903 |
| 2 | ME-045163 | PIÑON Z-18 AB.903 |
| 3 | ME-045167 | PIÑON Z-16 AB.903 |
| 4 | ME-045168 | PIÑON Z-20 AB.903 |
| 5 | ME-045156 | EJE ENTRADA AB.903 |
| 6 | ME-045157 | EJE SALIDA AB.903 |
| 7 | ME-045164 | EJE TRANSVERSAL |
| 8 | ME-045147 | PIÑON 1/2"X5/16"13Z TRANS. |
| 9 | ME-045158 | CASQUILLO MEDIANO |
| 10 | ME-045166 | CASQUILLO 32-26X75 |
| 11 | ME-045170 | ARANDELA 36-26X3 |
| 12 | HI-707009 | TAPÓN 3/8" GAS |
| 13 | 6885 8X7X20 | CHAVETA 6885 DE 8X7X20 |
| 14 | 6885 6X6X25 | CHAVETA 6885 DE 6X6X25 |
| 15 | FE-601038 | REten 25X52X7 |
| 16 | FE-601039 | REten 25X62X10 |
| 17 | FE-601040 | REten 35X62X10 |
| 18 | FE-660005 | TAPA-RCA 80X10 AB.903 |
| 19 | FE-660006 | TAPA-RCA 52X7 |
| 20 | 472 52 | ANILLO SAEGER 472 52 |
| 21 | 472 62 | ANILLO SAEGER 472 62 |
| 22 | 471 25 | ANILLO SAEGER 471 25 |
| 23 | FE-600097 | RODAMIENTO 6205 |
| 24 | FE-600096 | RODAMIENTO 6305 |



15.14 FERTILIZER D-903/3000

| Nº | REFERENCE | DESCRIPTION |
|-----------|-----------|---|
| 1 | RE-025200 | ALZA ABONADORA D-5/3000 |
| 2 | PS-035106 | CRIBA ALTA AB. D-903 FAB. ESPECIFICA |
| 3 | PS-2146 | TOLVA ABONADORA 903/3000 |
| 4 | PS-024100 | ÁNGULO DESCANSO TOLVA REFORZADO |
| 5 | PS-2147 | <U> ARTICULACIÓN TOLVA REFORZADA |
| 6 | ME-044100 | EJE UNIÓN TRANSMISIÓN D-903 |
| 7 | FE-600024 | RODAMIENTO 6007 2RS |
| 8 | 472 62 | ANILLO SAEGER DIN 472 Ø62 |
| 9 | PS-2150 | ENGANCHE ABONADORA D-5/3000 |
| 10 | MO-015200 | PIÉ ABONADORA D-5/3000, COMPLETO |
| 11 | CO-045101 | CILINDRO SE MANDO PALANCAS |
| 12 | PS-2151 | CORREDERA POLEA FRENO |
| 13 | ME-095200 | POLEA CABLE FRENO |
| 14 | PS-2180 | VARILLA TENSORA FRENO |
| 15 | EE-045202 | BIELA LARGA FRENO |
| 16 | PP-71 | PALANCA FRENO ESTACIONAMIENTO AB D-5/3000 |
| 17 | 471 35 | ANILLO SAEGER DIN 471 Ø35 |
| 18 | FE-608015 | TRANSMISIÓN CARDÁN L=1000 |



11. NOTES

| DATE | NOTES |
|------|-------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| DATE | NOTES |
|------|-------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

MAQUINARIA AGRÍCOLA SOLÁ, S.L.
Ctra. de Igualada, s/n. Apdo. Correos, 11
08280 CALAF (Barcelona) **ESPAÑA**
Tel. 34 93 868 00 60
Fax. 34 93 868 00 55
www.solagrupe.com
e-mail: sola@solagrupe.com

